

Michigan - Well C

	Well Name	Type of well	Well depth in feet	Water amount %	date of initial treatment
	Well C	Open Hole lateral 28 years old	11300	29%	17-Jun-04
Well problem	High Parrafin Build up				
Solution	Mix 5 drums of KX-100 with 80 barrels of oil and pump downhole. Wait 48 hours before starting well production. No Continuous Injection required.				

Well C	oil production (BNPD)	gas prod.(Mcf per day)
Before	35	0
After	61	80
Increase	26	80
Perc. Increase	74%	NA